FoMaKo
www.fomako.net

FoMaKo System Setup & Configuration Guide

PTZ Camera | PTZ Camera Controller | Video Mixer Switcher

1. Wiring : all device -> POE switch ->router

All device connect to a same router, if you have POE switch, so all device connect to POE switch , then the POE switch connect to a same router.

2. Make camera and controller connection (follow the attached video)

3. Set static IP for the camera in camera web UI(turn off DHCP, save settings, reboot and verify).

This keeps the IP fixed, and the controller will not lose camera control after reboot.

4. PTZ controller is for controlling PTZ camera (e.g. KC608 Pro, KC608N, KC600, KC606N)

It is not for trans video signal.

If you see a HDMI port on controller, this is for you to preview the LCD screen in a bigger HDMI monitor.

5. Select a second camera to operate with the PTZ Controller

KC608 Pro controller has 7 shortcut buttons, CAM1 ~ CAM7.

When you add more cameras, assign each camera to one of these buttons.

Just press the corresponding button to select and control that camera quickly.

If you have any problems, please feel free to contact us at : support@fomako.net

FoMaKo Supports Team